

Aim ^{Goal} :-

To study the effect of viscosity on the rate of filtration.

Reference :-

Requirements :-

- (a) Apparatus :- Beaker, filter paper, measuring cylinder.
- (b) ~~Glass~~ Chemical :- Glycerine, CaCO_3 , distilled water.

Theory :-

Principle :- Filtration is a process where solid particle suspension are separated from liquid or gas employing porous media which retain a solid particle but allow the fluid to pass through. Volume of filtration obtained through the filter paper per unit time is called rate of filtration.

eg: $\rightarrow \boxed{\frac{dv}{dt} = KA \cdot \Delta P / \mu L}$ - darcy's law.

Observation:

S. No.	Sample	Time taken	Volume of filtration	Rate of Fil.
1.	5% CaCO_3	342 sec	45 ml	0.13 ml/sec
2.	5% CaCO_3 + Glycerine	679 sec	45 ml	0.06 ml/sec

Calculation:

$$\text{Rate of filtration} = \frac{\text{Vol. of filtrate}}{\text{Time taken}}$$

$$(i) \text{ 5\% } \text{CaCO}_3 = \frac{45 \text{ ml}}{342 \text{ sec}} = 0.13 \text{ ml/sec}$$

$$(ii) \text{ 5\% } \text{CaCO}_3 + \text{Glycerine} = \frac{45 \text{ ml}}{679 \text{ sec}} = 0.06 \text{ ml/sec.}$$

where,

A = Area of filter,

V = Volume of filter,

K = Constant

ΔP = Pressure drop across the filter media and cake,

μ = Viscosity of filtrate,

L = Thickness of cake,

t = Time of filtration.

Procedure:

- (i) Take all glasswares and clean it and dry it.
- (ii) Preparation of 5% CaCO_3 solution:-
→ (a) Take 2.5 gm of CaCO_3 and dissolve into 50 ml of distilled water then prepare 5% of solution of CaCO_3 .
- (iii) Preparation of mixture of glycerine water and calcium carbonate.
(a) Take 2.5 gm of CaCO_3 and dissolve it into 40 ml of distilled water. Now add 10 ml of glycerine in this mixture.
- (iv) After preparation of solution filter with filter paper and note the time for filtration to calculate the rate of filtration and compare them.

Teacher's Signature _____

Result:-

The study of effect of rate of filtration was successfully performed in the laboratory.